


Third Reality

Smart Clock

Getting to know your Smart Clock



Setting up your Smart Clock

1. Follow the instructions in the Alexa app to set up your Echo Flex.
2. Ensure your Echo Flex is up to date by saying “Alexa, check for software updates”, and follow the instructions.
3. With Echo Flex plugged into a wall socket, insert your Smart Clock into Echo Flex’s USB port.
4. Alexa will automatically discover, connect and name the Smart Clock to “First device” or similar.
5. Go to the Devices page of the Alexa app to rename the Smart Clock.
6. If you can’t find the Smart Clock in your Alexa app after 1 minute, try restarting the app. If you still can’t find it, unplug the Smart Clock, plug it back in and then say “Alexa, discover my devices”.
7. For help and troubleshooting, visit the Alexa app.

WARNING: DO NOT EXPOSE TO WATER.

For troubleshooting, warranty and safety information, visit www.3reality.com/devicesupport

Using your Smart Clock

Your Smart Clock will display the time in a 12-hour or 24-hour format based on the time zone you have set up for Echo Flex in the Alexa app.

You can ask Alexa to change the time format using Third Reality’s Skill. Go to the “Skills” section in the Alexa app, search for “Third Reality Gadgets” and enable the skill. Then say “Alexa, open Third Reality.” and follow the prompts.

The display’s brightness will automatically adjust using the Smart Clock’s built-in light sensor. You can manually change the brightness using Alexa.

“Alexa, set the First Clock brightness to 50%.” or “Alexa, turn off the First Clock.”

Note that if you change the Smart Clock’s brightness, the light sensor will be disabled.

To turn the light sensor back on, unplug the Smart Clock and plug it back in.

This Guide is an independent publication of Third Reality, which is solely responsible for its content. Amazon has not reviewed its claims for accuracy. Amazon, Alexa, Echo and all related logos are trademarks of Amazon.com, Inc., or its affiliates.